

AVMC PA SYSTEM - GUIDELINES (22 FEB 2025)

IMPORTANT NOTES:


- **DO NOT** turn off/on any equipment switches inside the PA System Cabinet.
- **DO NOT** change any settings inside the PA System Cabinet.
- If required, please consult Bro Foo (0164935410) before making any changes.

STEPS TO USE THE PA SYSTEM:

- Turn **ON** the [Power Regulator] **ONLY** (See Picture on the right)
- The wireless microphones are kept inside the drawer (labelled as "MIC") inside the PA system cabinet. Install 2 AA batteries for the wireless mic.

STEPS AFTER USING THE PA SYSTEM:

- Turn **OFF** the [Power Regulator] **ONLY** (See Picture on the right)
- Please remember to **remove the batteries in the wireless mics** after use. The batteries may leak if left inside the wireless mics for months.



EXTRA FEATURES:

TO RECORD AUDIO (via MP3 RECORDER)

- For audio recording, insert a USB Pendrive into the USB port of the MP3 Recorder. (Component labelled [1])
- Press the **RECORD** button once. Recording will start automatically after approximately 5 seconds.
- Press the **STOP** button to end recording.
- **IMPORTANT:** After pressing the STOP button, please **wait for at least 1 minute before removing the USB Pendrive** to avoid mp3 file corruption. This is to allow the recorded file to be written to the Pendrive completely.

TO PLAY MP3 FILE (via USB Pendrive)

- Insert the USB Pendrive to the USB port of either:
 - Recorder (Component labelled [1])
 - Mixer (Component labelled [2]), or
- Press either the **NEXT** or **PREVIOUS** button to select the track to play.
- Press the **PLAY/STOP** button to start/stop the playback.

TO PLAY FROM HANDPHONE (via BLUETOOTH)

- Press the **MODE** button of the Mixer (Component labelled [2]) to switch to **"BLUETOOTH"** mode (display will switch from "NO" to "BLUE") (See Pictures on the right)
- Perform Bluetooth Pairing to pair your phone to the Mixer (you should see a device called "Audio" when you perform Bluetooth device discovery).



TROUBLESHOOTING (FOR ADVANCED USERS ONLY)

IMPORTANT NOTES:

- **DO NOT** turn off/on any equipment switches inside the PA System Cabinet.
 - **DO NOT** change any settings inside the PA System Cabinet.
 - If required, please consult Bro Foo (0164935410) before making any changes.
- Thank you.**

COMPONENTS OF THE PA SYSTEM (as labelled in the diagram in the main guide)


- [1] (MP3 Recorder) - For audio recording, please see the section in the main guide..
- [2] (Mixer) - The power switch is at the back of the mixer.
- [3] (Wireless microphone set #1) - For BLUE & ORANGE wireless microphones.
- [4] (Wireless microphone set #2) - For YELLOW wireless & BEIGE wear-on microphones.
- [5] (Amplifier) - Amplifier for speakers in the meditation hall.
- [6] (Horn speaker) - Amplifier for outdoor loudspeaker. **[DISABLED / NOT USED ANYMORE.]**

MIC VOLUME ADJUSTMENT

The Mixer settings (Component labelled [2]) should **NOT** need to be adjusted under normal circumstances. However, if someone has messed up the settings during previous use, and you may need to re-adjust the sliders so that the volume is at an acceptable level again.

You may adjust the slider up or down for the respective input channels **ONLY IF** any of the following happens:

- The microphone volume is too soft, or
- The microphone volume is too loud, or
- Some distortion (from audio feedback), or
- No sound from the microphones / MP3 player / your phone (via Bluetooth)



The sliders on the Mixer are labelled based on the colour rings:

- WIRED MIC - for Sayalay's mic on the table
- BLUE - for wireless mic with blue ring
- ORANGE - for wireless mic with orange ring
- YELLOW - for wireless mic with yellow ring.

Please do NOT swap the plastic colour rings attached to the wireless mic to prevent confusion to others. Thank you.



NOTE: Please consult Bro Foo (0164935410) if you are not sure of what you are changing, so that you don't mess up the settings and cause problems for the next user. Thank you very much for your kind cooperation.